

# SDM-CD16D

## 16-Channel Digital Control Port Expansion Module



The SDM-CD16D increases the number of digital outputs that can be controlled (i.e., set to 0 or 5 V) by a Campbell Scientific datalogger. In addition to being able to drive normal logic level inputs, when an output is set HI, a boost circuit allows it to source a current of up to 100 mA for controlling low voltage valves, relays, or other devices.

### SDM Operation

The SDM-CD16D is a synchronously addressed datalogger peripheral. Datalogger control ports 1, 2, and 3 are used to address the SDM-CD16D then clock out the desired state of each of the 16 control ports. Up to 16 SDM-CD16Ds may be addressed, making it possible to control a maximum of 256 ports from the first three datalogger control ports.

### Datalogger Connection

The CABLE5CBL-L is recommended for connecting the module to the datalogger. A 1-ft cable length should be sufficient when both datalogger and SDM-CD16D are housed within an ENC12/14 enclosure; a 2-ft length may be required if the datalogger and SDM-CD16D are housed at opposite ends of an ENC16/18 Enclosure.

The cable length should be as short as possible. Typically, the maximum cable length is 20 ft. Contact Campbell Scientific if the length needs to be longer.

### Power Considerations

The SDM-CD16D power requirements are large compared to most Campbell Scientific products when driving significant loads. For many applications an external power supply is recommended to power the SDM-CD16D. For some applications, it may be convenient to use the datalogger supply to power the SDM-CD16D.

For long-term applications, the sealed rechargeable power supply available with Campbell Scientific dataloggers should be used, allowing the batteries to be float charged. Alkaline batteries are not recommended for long-term applications.



The SDM-CD16D is intended for low voltage, low power applications not suitable for the SDM-CD16AC. The unit cost is also considerably lower.

### Ordering Information

#### Synchronous Device for Measurement

**SDM-CD16D** 16-Channel Digital Control Port Expansion Module

#### SDM-to-Datalogger Cable

**CABLE5CBL-L** 5-conductor, 24 AWG cable with drain wire and Santoprene jacket. Enter cable length, in feet, after the -L. Must choose a cable termination option (see below).

#### Cable Termination Options (choose one)

- PT** Cable terminates in stripped and tinned leads for direct connection to a datalogger's terminals.
- PW** Cable terminates in connector for attachment to a prewired enclosure.

### Specifications

#### Compatible Dataloggers:

CR800, CR850, CR1000, CR3000, CR5000 (OS version 1.3 or higher), CR7, CR10(X), CR23X, and 21X. The SDM-CD16D is not compatible with the CR500, CR510, and CR200-series dataloggers.

#### Power

##### Operating Voltage:

12 Vdc nominal (9 to 18 Vdc)

##### Current Drain @ 12 Vdc:

100  $\mu$ A typical (all ports HI, no load)

## Specifications Continued

### Environmental

**Operating Temperature:** -25° to +70°C

### Physical

**Dimensions:** 9-in. x 4-in. x1-in.  
(23-cm x 10-cm x2.4-cm)

**Weight:** 0.77 lbs (0.35 kg)

**EMC Status:** Complies with EN55022-1:1998  
and EN50082-1:1998

### Output

**Output Voltage (no load):** Output ON/HI, Nominal 5 V  
(Minimum 4.5 V)

**Output OFF/LO:** Nominal 0 V (Maximum 0.1 V)

**Output Sink Current:** Output will sink 8.6 mA  
from a 5 V source

**Output Source Current:** Output will source 36 mA @ 3 V,  
115 mA short-circuited to ground

**Maximum Output Current<sup>1</sup>:** 400 mA at 50°C & 12 V supply

<sup>1</sup>The maximum current (total all outputs) should be derated by 50 mA for every 10°C above 50°C and/or 50 mA for every voltage above 12 V.



Campbell Scientific, Inc. | 815 W 1800 N | Logan, Utah 84321-1784 | (435) 753-2342 | [www.campbellsci.com](http://www.campbellsci.com)  
USA | AUSTRALIA | BRAZIL | CANADA | COSTA RICA | ENGLAND | FRANCE | GERMANY | SOUTH AFRICA | SPAIN

Copyright © 2006, 2009  
Campbell Scientific, Inc.  
Printed September 2009